

Gas Care



Important LPG Safety Tips

- Store cylinder in a well ventilated area
- Use a cylinder sealing plug to reduce danger from leaks
- Always keep cylinder upright
- Have your cylinder safety inspected every 10 years

Connecting the Gas Cylinder

- Before connecting the cylinder, inspect the hose, fittings and rubber seals
- If there is any sign of splitting or wear, have the hose replaced
- Make sure all connections are tightened with a spanner and then conduct this simple test:
 - o Turn the gas on at the cylinder without turning on the barbeque
 - o Brush soapy water on all the connections
 - o If bubbles appear, then there is a leak
- Keep the hose free of knots & kinks

Transporting a Gas Cylinder

- Ensure cylinder has been leak tested
- Always keep bottle upright and protected from falling over
- Drive with the windows open
- Do not store cylinder in a plastic milk crate as this may cause static electricity to build up
- Do not light a flame or cigarette close to the cylinder
- Do not leave the cylinder unattended in a vehicle
- Do not expose the cylinder to direct heat or sunlight in a vehicle or exposed area
- Drive slowly and with care